



Printer Compatibility List

Update:2015.01.10

Printer Manufacture	Printer Model	Print Server Model
		GPSU21
		1U
HP	Business InkJet 1000	OK
HP	Color Laserjet 1500L	OK
HP	Color Laserjet 1600	OK
HP	Color Laserjet 2500	OK
HP	Color LaserJet 2550	OK
HP	Color LaserJet 2550L/LN	OK
HP	Color LaserJet 2600	OK
HP	Color LaserJet 2605	OK
HP	Color LaserJet 2700n	OK
HP	Color LaserJet 2840	OK
HP	Color LaserJet 3700	OK
HP	Color Laserjet 4650	OK
HP	Color Laserjet CP1215	OK
HP	Color Laserjet CP1525nw	OK
HP	Color Laserjet CM1312 MFP	OK
HP	Color Laserjet CM1015 MFP	OK
HP	Designjet 100	OK
HP	Deskjet 1125C	OK
HP	Deskjet 1180C	OK
HP	DeskJet 1280	OK
HP	Deskjet 2000 J210	OK
HP	Deskjet 2020hc	OK
HP	Deskjet 2050	OK
HP	Deskjet 2510	OK
HP	Deskjet IA 2520hc	OK
HP	Deskjet 2540	OK
HP	Deskjet 3000	OK
HP	Deskjet 3070A	OK
HP	Deskjet 3050	OK
HP	Deskjet 3325	OK
HP	DeskJet 3420	OK
HP	Deskjet 3520	OK
HP	Deskjet 3535	OK
HP	Deskjet 3650	OK
HP	Deskjet 3743	OK
HP	Deskjet 3748	OK
HP	Deskjet 3820	OK
HP	DeskJet 3920	OK
HP	DeskJet 3940	OK
HP	Deskjet 450C	OK
HP	DeskJet 5440	OK



HP	Deskjet 5550	OK
HP	Deskjet 5652	OK
HP	Deskjet 810C	OK
HP	Deskjet 830C	OK
HP	Deskjet 845C	OK
HP	DeskJet 9300	OK
HP	Deskjet 948c	OK
HP	Deskjet 9600	OK
HP	Deskjet 9650	OK
HP	Deskjet 970c XI	OK
HP	Deskjet 9800	OK
HP	Deskjet D1560	OK
HP	Deskjet D2560	OK
HP	Deskjet D5560	OK
HP	DeskJet F370	OK
HP	DeskJet F380	OK
HP	DeskJet F4185	OK
HP	DeskJet F4280	OK
HP	Deskjet F4480	OK
HP	Laserjet Pro M401n	OK
HP	Laserjet M1005 MFP	OK
HP	LaserJet 1022	OK
HP	LaserJet 1022N	OK
HP	LaserJet 1200	OK
HP	LaserJet 1220	OK
HP	Laserjet 1300	OK
HP	Laserjet 1320	OK
HP	Laserjet M1522n MFP	OK
HP	Laserjet 2200d	OK
HP	LaserJet 2410	OK
HP	LaserJet 2420	OK
HP	LaserJet 2550	OK
HP	LaserJet 3015	OK
HP	LaserJet 3050	OK
HP	LaserJet 3055	OK
HP	Laserjet 3200	OK
HP	Laserjet 3330	OK
HP	LaserJet 3330mfp	OK
HP	LaserJet 3380	OK
HP	LaserJet 4250	OK
HP	Laserjet 4650	OK
HP	Laserjet M1005	OK
HP	Laserjet M1005 MFP	OK
HP	Laserjet M1120 MFP	OK
HP	LaserJet M1319F MFP	OK
HP	LaserJet P2015	OK



HP	Laserjet Pro M127fn	OK
HP	Laserjet Pro M1536dnf	OK
HP	Laserjet Pro M425dn MFP	OK
HP	Laserjet Pro M521dn	OK
HP	Officejet J3608	OK
HP	Officejet 2620	OK
HP	OfficeJet 4255	OK
HP	Officejet 4500	OK
HP	Officejet 4610	OK
HP	Officejet 4620	OK
HP	Officejet 4630	OK
HP	OfficeJet 5610	OK
HP	Officejet J5780	OK
HP	OfficeJet 6210	OK
HP	OfficeJet 6310	OK
HP	Officejet 6000	OK
HP	Officejet 6100 eP	OK
HP	Officejet 6500	OK
HP	Officejet 6600	OK
HP	Officejet 6700	OK
HP	Officejet 7500A	OK
HP	OfficeJet 7210	OK
HP	OfficeJet J4580	OK
HP	Officejet J4660	OK
HP	Officejet J6480	OK
HP	Officejet K7100	OK
HP	OfficeJet K850	OK
HP	OfficeJet Pro K5300	OK
HP	OfficeJet Pro K550	OK
HP	OfficeJet Pro K8600	OK
HP	Officejet Pro L7380	OK
HP	Officejet Pro L7590	OK
HP	Officejet Pro 6500A Plus	OK
HP	Officejet Pro 7000	OK
HP	Officejet Pro 8000	OK
HP	Officejet Pro 8100	OK
HP	Officejet Pro 8500A Plus	OK
HP	Officejet Pro 8500W	OK
HP	Officejet Pro 8600	OK
HP	Officejet Pro 8600 Plus	OK
HP	Photosmart 2610	OK
HP	Photosmart 3110	OK
HP	Photosmart 5510	OK
HP	Photosmart 5520	OK
HP	Photosmart 6510	OK
HP	Photosmart 6520	OK



HP	Photosmart 7150	OK
HP	Photosmart 7200	OK
HP	Photosmart 7510	OK
HP	Photosmart 7550	OK
HP	Photosmart 7660	OK
HP	Photosmart 7830	OK
HP	Photosmart 7900	OK
HP	Photosmart 8200	OK
HP	Photosmart Plus B209a	OK
HP	Photosmart Plus B210a	OK
HP	Photosmart Plus C310a	OK
HP	Photosmart A520	OK
HP	Photosmart B109a	OK
HP	Photosmart B110a AIO	OK
HP	Photosmart C309a	OK
HP	Photosmart C410a	OK
HP	Photosmart C3180	OK
HP	Photosmart C4180	OK
HP	Photosmart C4280	OK
HP	Photosmart C4385	OK
HP	Photosmart C4480	OK
HP	Photosmart C4580	OK
HP	Photosmart C5180	OK
HP	Photosmart C5280	OK
HP	Photosmart C5380	OK
HP	Photosmart C6180	OK
HP	Photosmart C6280	OK
HP	Photosmart C6380	OK
HP	Photosmart C7180	OK
HP	Photosmart C7280	OK
HP	Photosmart C8180	OK
HP	Photosmart D5160	OK
HP	Photosmart D5360	OK
HP	Photosmart D5460	OK
HP	Photosmart D7160	OK
HP	Photosmart D7260	OK
HP	Photosmart D7360	OK
HP	Photosmart Premium C309g	OK
HP	Photosmart Premium C310g	OK
HP	PSC 1315	OK
HP	PSC 1350	OK
HP	PSC 1410	OK
HP	PSC 1610	OK
HP	PSC 2210	OK
HP	PSC 2310	OK
EPSON	Aculaser C1100SE	OK



EPSON	Aculaser C1600	OK
EPSON	Aculaser C1700	OK
EPSON	Aculaser C1750N	OK
EPSON	Aculaser C1750W	OK
EPSON	Aculaser C1900	OK
EPSON	Aculaser C2900	OK
EPSON	Aculaser C3800	OK
EPSON	Aculaser C3900N	OK
EPSON	Aculaser C9100	OK
EPSON	Aculaser CX16NF	OK
EPSON	Aculaser CX17NF	OK
EPSON	Aculaser M1400	OK
EPSON	Aculaser M2010DN	OK
EPSON	Aculaser M2010D	OK
EPSON	Aculaser M2310D	OK
EPSON	Aculaser M2310DN	OK
EPSON	Aculaser M2410D	OK
EPSON	Aculaser M2410DN	OK
EPSON	Aculaser MX14	OK
EPSON	Aculaser MX14NF	OK
EPSON	AL-M200DN	OK
EPSON	AL-M7000	OK
EPSON	AL-M8000	OK
EPSON	AL-MX200DWF	OK
EPSON	B-508DN	OK
EPSON	B-518DN	OK
EPSON	C750	OK
EPSON	CC-500L	OK
EPSON	CL-760	OK
EPSON	E-300L	OK
EPSON	E-520	OK
EPSON	E-720	OK
EPSON	EC-01	OK
EPSON	EPL 5800	OK
EPSON	EPL 5800	OK
EPSON	EPL 5900	OK
EPSON	EPL 6100	OK
EPSON	EPL 6200	OK
EPSON	K100	OK
EPSON	L110	OK
EPSON	L120	OK
EPSON	L200	OK
EPSON	L210	OK
EPSON	L350	OK
EPSON	L355	OK
EPSON	L300	OK



EPSON	L550	OK
EPSON	L555	OK
EPSON	L800	OK
EPSON	L1300	OK
EPSON	L1800	OK
EPSON	LP2500	OK
EPSON	LP-7700	OK
EPSON	LP-8700	OK
EPSON	LP-8800C	OK
EPSON	LP8900	OK
EPSON	LP-9500C	OK
EPSON	LQ 2090C	OK
EPSON	LQ 2190C	OK
EPSON	LQ 300+II	OK
EPSON	LQ-310	OK
EPSON	M105	OK
EPSON	ME 320	OK
EPSON	ME 340	OK
EPSON	ME Office 82WD	OK
EPSON	ME Office 900WD	OK
EPSON	ME Office 940FW	OK
EPSON	ME Office 960FWD	OK
EPSON	MC-2000	OK
EPSON	PictureMate PM250	OK
EPSON	PLQ-20C	OK
EPSON	PLQ-20CM	OK
EPSON	PM-860PT	OK
EPSON	PM-890C	OK
EPSON	PM-920C	OK
EPSON	PM-930C	OK
EPSON	PM-950C	OK
EPSON	PM-970C	OK
EPSON	PM-980C	OK
EPSON	PM-A550	OK
EPSON	PM-A620	OK
EPSON	PM-A650	OK
EPSON	PM-A720	OK
EPSON	PM-A820	OK
EPSON	PM-A840	OK
EPSON	PM-A850	OK
EPSON	PM-A890	OK
EPSON	PM-A900	OK
EPSON	PM-A920	OK
EPSON	PM-A940	OK
EPSON	PM-A950	OK
EPSON	PM-A970	OK



EPSON	PM-2200C	OK
EPSON	PM-3500C	OK
EPSON	PM-3700C	OK
EPSON	PM-4000PX	OK
EPSON	PM-D800	OK
EPSON	PM-D870	OK
EPSON	PM-D1000	OK
EPSON	PM-FA700	OK
EPSON	PM-G800	OK
EPSON	PM-G820	OK
EPSON	PM-G850	OK
EPSON	PM-G860	OK
EPSON	PM-G4500	OK
EPSON	PM-T960	OK
EPSON	PM-T990	OK
EPSON	PX-5000	OK
EPSON	PX-A640	OK
EPSON	PX-A740	OK
EPSON	PX-G5300	OK
EPSON	PX-G5100	OK
EPSON	PX-G930	OK
EPSON	PX-G5000	OK
EPSON	PX-V780	OK
EPSON	RX 510	OK
EPSON	RX 530	OK
EPSON	RX 590	OK
EPSON	RX 630	OK
EPSON	RX 690	OK
EPSON	Stylus C20	OK
EPSON	Stylus C40	OK
EPSON	Stylus C41UX/SX	OK
EPSON	Stylus C43UX	OK
EPSON	Stylus C45	OK
EPSON	Stylus C59	OK
EPSON	Stylus C60	OK
EPSON	Stylus C63	OK
EPSON	Stylus C67	OK
EPSON	Stylus C79	OK
EPSON	Stylus C90	OK
EPSON	Stylus Color 1160	OK
EPSON	Stylus Color 1500	OK
EPSON	Stylus Color 1520	OK
EPSON	Stylus Color 670	OK
EPSON	Stylus Color 800	OK
EPSON	Stylus Color 810	OK
EPSON	Stylus Color 850	OK



EPSON	Stylus Color 900	OK
EPSON	Stylus CX-1500	OK
EPSON	Stylus CX-2900	OK
EPSON	Stylus CX-3500	OK
EPSON	Stylus CX-3700	OK
EPSON	Stylus CX-3900	OK
EPSON	Stylus CX-4100	OK
EPSON	Stylus CX-4700	OK
EPSON	Stylus CX-4900	OK
EPSON	Stylus CX-5300	OK
EPSON	Stylus CX-5500	OK
EPSON	Stylus CX-5505	OK
EPSON	Stylus CX-5900	OK
EPSON	Stylus CX-6900F	OK
EPSON	Stylus CX-7300	OK
EPSON	Stylus CX-7800	OK
EPSON	Stylus CX-8300	OK
EPSON	Stylus CX-9300F	OK
EPSON	Stylus Office T30	OK
EPSON	Stylus Office T40W	OK
EPSON	Stylus Office TX300F	OK
EPSON	Stylus Office TX320F	OK
EPSON	Stylus Office TX510FN	OK
EPSON	Stylus Office TX600FW	OK
EPSON	Stylus Office TX610FW	OK
EPSON	Stylus Office T1100	OK
EPSON	Stylus Photo 915	OK
EPSON	Stylus Photo 1270	OK
EPSON	Stylus Photo 1290	OK
EPSON	Stylus Photo 1390	OK
EPSON	Stylus Photo 2100	OK
EPSON	Stylus Photo 710	OK
EPSON	Stylus Photo 720	OK
EPSON	Stylus Photo 790	OK
EPSON	Stylus Photo 810	OK
EPSON	Stylus Photo 830U	OK
EPSON	Stylus Photo 900	OK
EPSON	Stylus Photo 915	OK
EPSON	Stylus Photo EX2	OK
EPSON	Stylus Photo EX3	OK
EPSON	Stylus Photo R1800	OK
EPSON	Stylus Photo R210	OK
EPSON	Stylus Photo R230	OK
EPSON	Stylus Photo R250	OK
EPSON	Stylus Photo R270	OK
EPSON	Stylus Photo R310	OK



EPSON	Stylus Photo R350	OK
EPSON	Stylus Photo R2400	OK
EPSON	Stylus Photo R800	OK
EPSON	Stylus Photo RX430	OK
EPSON	Stylus Photo RX 510	OK
EPSON	Stylus Photo RX 530	OK
EPSON	Stylus Photo RX 590	OK
EPSON	Stylus Photo RX 630	OK
EPSON	Stylus Photo RX 650	OK
EPSON	Stylus Photo RX 690	OK
EPSON	Stylus Photo R2880	OK
EPSON	Stylus Photo TX700W	OK
EPSON	Stylus Photo TX800FW	OK
EPSON	Stylus Photo TX820FWD	OK
EPSON	Stylus Pro 7600	OK
EPSON	Stylus TX550W	OK
EPSON	Stylus TX420W	OK
EPSON	Stylus TX410	OK
EPSON	Stylus TX430	OK
EPSON	Stylus TX235	OK
EPSON	Stylus TX220	OK
EPSON	Stylus TX200	OK
EPSON	Stylus TX210	OK
EPSON	Stylus TX130	OK
EPSON	Stylus TX110	OK
EPSON	Stylus TX100	OK
EPSON	Stylus T22	OK
EPSON	Stylus T20	OK
EPSON	Stylus T21	OK
EPSON	Stylus Photo T50	OK
EPSON	WorkForce AL-M300D	OK
EPSON	WorkForce AL-M300DN	OK
EPSON	WorkForce AL-M400D	OK
EPSON	WF-2521	OK
EPSON	WF-2531	OK
EPSON	WF-2541	OK
EPSON	WF-3521	OK
EPSON	WorkForce WF-3541	OK
EPSON	WF-5191	OK
EPSON	WF-5621	OK
EPSON	WF-7011	OK
EPSON	WF-7511	OK
EPSON	WF-7521	OK
EPSON	WP-4531	OK
EPSON	WP-4091	OK
EPSON	XP30	OK



EPSON	XP-102	OK
EPSON	XP-202	OK
EPSON	XP-302	OK
EPSON	XP-402	OK
EPSON	XP-701	OK
EPSON	GP-C830	OK
EPSON	GP-M800	OK
EPSON	GP-C800	OK
EPSON	AL-C500	OK
EPSON	AL-C9300	OK
Canon	BJF9000	OK
Canon	D380	OK
Canon	E400	OK
Canon	E600	OK
Canon	I-255	OK
Canon	I-355	OK
Canon	I-450	OK
Canon	I-455	OK
Canon	I-470D	OK
Canon	I-475D	OK
Canon	I-550	OK
Canon	I-560	OK
Canon	I-850	OK
Canon	I-865	OK
Canon	I-950	OK
Canon	I-6100	OK
Canon	I-6500	OK
Canon	I-9100	OK
Canon	I-9950	OK
Canon	IX4000	OK
Canon	IX5000	OK
Canon	IX6770	OK
Canon	Imageclass D380	OK
Canon	MP-160	OK
Canon	MP-638	OK
Canon	MP 770	OK
Canon	PIXMA MX318	OK
Canon	PIXMA MX320	OK
Canon	PIXMA MX357	OK
Canon	PIXMA MX377	OK
Canon	PIXMA MX397	OK
Canon	PIXMA MX416	OK
Canon	PIXMA MX457	OK
Canon	PIXMA MX477	OK
Canon	PIXMA MX527	OK
Canon	PIXMA MX700	OK

Canon	PIXMA MX727	OK
Canon	PIXMA MX927	OK
Canon	PIXUS IP2500	OK
Canon	PIXUS 990i	OK
Canon	PIXMA E510	OK
Canon	PIXMA iP1000	OK
Canon	PIXMA iP1700	OK
Canon	PIXMA iP1800	OK
Canon	PIXMA Ip1880	OK
Canon	PIXMA Ip1980	OK
Canon	PIXMA Ip2000	OK
Canon	PIXMA Ip2870	OK
Canon	PIXMA iP3000	OK
Canon	PIXMA Ip3300	OK
Canon	PIXMA Ip3500	OK
Canon	PIXMA Ip3680	OK
Canon	PIXMA iP4000	OK
Canon	PIXMA Ip4200	OK
Canon	PIXMA Ip4300	OK
Canon	PIXMA Ip4500	OK
Canon	PIXMA Ip4760	OK
Canon	PIXMA ip4970	OK
Canon	PIXMA Ip5000	OK
Canon	PIXMA Ip6000	OK
Canon	PIXMA Ip7270	OK
Canon	PIXMA Ip8500	OK
Canon	PIXMA Ip8770	OK
Canon	PIXMA MG2270	OK
Canon	PIXMA MG2470	OK
Canon	PIXMA MG2570	OK
Canon	PIXMA MG2970	OK
Canon	PIXMA MG3170	OK
Canon	PIXMA MG3270	OK
Canon	PIXMA MG3570	OK
Canon	PIXMA MG4270	OK
Canon	PIXMA MG5470	OK
Canon	PIXMA MG5570	OK
Canon	PIXMA MG5670	OK
Canon	PIXMA MG6170	OK
Canon	PIXMA MG6270	OK
Canon	PIXMA MG6370	OK
Canon	PIXMA MG7170	OK
Canon	PIXMA MG7570	OK
Canon	PIXMA MP110	OK
Canon	PIXMA MP130	OK
Canon	PIXMA MP145	OK



Canon	PIXMA MP150	OK
Canon	PIXMA MP180	OK
Canon	PIXMA MP237	OK
Canon	PIXMA MP258	OK
Canon	PIXMA MP450	OK
Canon	PIXMA MP730	OK
Canon	PIXMA MP780	OK
Canon	PIXMA MP830	OK
Canon	S-200SPX	OK
Lexmark	E230	OK
Lexmark	E322	OK
Lexmark	P4350	OK
Lexmark	P6250	OK
Lexmark	T420	OK
Lexmark	T620	OK
Lexmark	W812	OK
Lexmark	Z42	OK
Lexmark	Z43	OK
Lexmark	Z45	OK
Lexmark	Z55	OK
Lexmark	Z515	OK
Lexmark	Z615	OK
Lexmark	Z705	OK
FUJI Xerox	DocuP 2050	OK
FUJI Xerox	DocuP 240A	OK
FUJI Xerox	DocuP C1110B	OK
FUJI Xerox	DocuP CM205 f	OK
FUJI Xerox	DocuP CP105 b	OK
FUJI Xerox	DocuP P205 b	OK
FUJI Xerox	DocuP M205 b	OK
FUJI Xerox	DocuP M205 f	OK
FUJI Xerox	DocuP M205 fw	OK
FUJI Xerox	Phaser 3310	OK
Konica Minolta	magicolor 2450	OK
Konica Minolta	magicolor 5450	OK
Konica Minolta	magicolor 7300	OK
Konica Minolta	Magicolor 7300	OK
Konica Minolta	PagePro 1350W	OK
Konica Minolta	PagePro 9100	OK
Samsung	CLP-315	OK
Samsung	CLP-500	OK
Samsung	CLP-510	OK
Samsung	CLP-620ND	OK
Samsung	CLP-661NDK	OK
Samsung	CLP-670NDK	OK
Samsung	CLP-680ND	OK



Samsung	CLP-775N	OK
Samsung	CLX2160	OK
Samsung	ML-1510/1710	OK
Samsung	ML-1520	OK
Samsung	ML-1660	OK
Samsung	ML-1710	OK
Samsung	ML-1750	OK
Samsung	ML-1915	OK
Samsung	ML-2010	OK
Samsung	ML-2165W	OK
Samsung	ML-2250	OK
Samsung	ML-2550	OK
Samsung	ML-2580N	OK
Samsung	ML-2580NK	OK
Samsung	ML-3471ND	OK
Samsung	ML-4555N	OK
Samsung	ML-5010ND	OK
Samsung	ML-5015ND	OK
Samsung	ML-8951N	OK
Samsung	SL-M2620ND	OK
Samsung	SCX-4016	OK
Samsung	SCX-4100/4106/4116/4216F	OK
Panasonic	KX-MB1500TW	OK
Panasonic	KX-MB1520TW	OK
Panasonic	KX-MB1530TW	OK
IBM	InfoP 1116	OK
IBM	InfoP 1312	OK
IBM	InfoP 1316	OK
IBM	InfoP 1332	OK
IBM	InfoP 1412	OK
Brother	MFC 1815	OK
Brother	MFC 4800	OK
Brother	MFC 4800J	OK
Brother	MFC 6800	OK
Brother	MFC 7220	OK
Brother	MFC 7420	OK
Brother	MFC 7820N	OK
Brother	MFC 8840D	OK
Brother	MFC 210C	OK
Brother	MFC 240C	OK
Brother	MFC-J200	OK
Brother	MFC-J2320	OK
Brother	MFC-J3520	OK
Brother	MFC-J430W	OK
Brother	MFC-J825DW	OK
Brother	DCP-J100	OK

Brother	DCP-J105	OK
Brother	DCP-7030	OK
Brother	HL-1110	OK
Brother	HL-2140	OK
Brother	HL-2170W	OK
Brother	HL-2240D	OK
Brother	IntelliFax 2820	OK
Others	OKI B4350	OK
Others	BENQ CM3000	OK
Avision	MF 3200	OK
	MF 3230	OK
DOCUJET	1610F	OK
	UA1610	OK
Kyocera	FS-1010	OK
	FS-1010KX	OK
	FS-1020	OK
	FS-1920	OK
	FS-2000D	OK
	FS-820	OK
	FS-920	OK
	FS-6020	OK
	FS-6026	OK