



Final Update : 2007.03.02

Printer's Brand	Printer's Type	Printer Compatibility list
		GPSU21
Avision	MF 3200	●
Avision	MF 3230	●
Brother	HL1260	
Brother	MFC4800	●
Brother	MFC4800J	●
Brother	MFC6800	●
Brother	MFC7220	●
Brother	MFC7420	●
Brother	MFC8840D	●
Brother	MFC210C	●
Brother	IntelliFax 2820	●
CANON	S520	
CANON	S200SPX	●
CANON	I450	●
CANON	I550	●
CANON	I850	●
CANON	I950	●
CANON	I255	●
CANON	I355	●
CANON	I455	●
CANON	I470D	●
CANON	I475D	●
CANON	I560	●
CANON	I850	●
CANON	I865	●
CANON	I905D	
CANON	I6100	●
CANON	I6500	●
CANON	I9100	●
CANON	I9950	●
CANON	IX4000	●
CANON	IX5000	●
CANON	Imageclass D380	●
CANON	BJ-330	
CANON	BJC-620	
CANON	BJC4200	

CANON	BJC4300	
CANON	BJC4550	
CANON	BJC4650	
CANON	BJF9000	●
CANON	PIXMA ip1000	●
CANON	PIXMA ip2000	●
CANON	PIXMA ip3000	●
CANON	PIXMA ip4000	●
CANON	PIXMA ip4200	●
CANON	PIXMA ip5000	●
CANON	PIXMA ip6000	●
CANON	PIXMA ip8500	●
CANON	MP-110	●
CANON	MP-130	●
CANON	MP730	●
CANON	MP770	●
Citizen	GSX230	
DATAMAX	I-4208	
DATAMAX	I-4308	
DOCUJET	1610F	●
DOCUJET	UA1610	●
EPSON	C750	●
EPSON	CX 1500	●
EPSON	LQ-100	
EPSON	LQ-300	
EPSON	LQ-300+	
EPSON	LQ-300+II	●
EPSON	LQ-570C	
EPSON	LQ-1000C	
EPSON	LQ-1170+	
EPSON	LQ-1170C+	
EPSON	LQ-1170C	
EPSON	LQ-2070C	
EPSON	LQ-2080C	
EPSON	LQ-2090	
EPSON	LQ-2090C	●
EPSON	LQ-2170C	
EPSON	LQ-2180C	
EPSON	LQ-2550	
EPSON	LQ-3500C	
EPSON	LQ-670	
EPSON	LQ-680	
EPSON	LQ-680C	
EPSON	STYLUS C20	●

EPSON	STYLUS C40	●
EPSON	STYLUS C41UX	●
EPSON	STYLUS C43UX	●
EPSON	STYLUS C45	●
EPSON	STYLUS C60	●
EPSON	Stylus C63	●
EPSON	Stylus C67	●
EPSON	Stylus C83	
EPSON	Stylus Color 400	
EPSON	Stylus Color 600	
EPSON	Stylus Color 670	●
EPSON	Stylus Color 800	●
EPSON	Stylus Color 810	●
EPSON	Stylus Color 850	●
EPSON	Stylus Color 900	●
EPSON	Stylus Color 1160	●
EPSON	Stylus Color 1520	●
EPSON	Stylus CX-1500	●
EPSON	Stylus CX-2900	●
EPSON	Stylus CX-3500	●
EPSON	Stylus CX-3700	●
EPSON	Stylus CX-3900	●
EPSON	Stylus CX-4100	●
EPSON	Stylus CX-4700	●
EPSON	Stylus CX-4900	●
EPSON	Stylus CX-5300	●
EPSON	Stylus CX-5900	●
EPSON	Stylus CX-6900F	●
EPSON	Stylus CX-7800	●
EPSON	Stylus Pro 7600	●
EPSON	Stylus Photo 915	●
EPSON	Stylus Photo 1270	●
EPSON	Stylus Photo 1290	●
EPSON	Stylus Photo 2100	●
EPSON	Stylus Photo 710	●
EPSON	Stylus Photo 720	●
EPSON	Stylus Photo 790	●
EPSON	Stylus Photo 810	●
EPSON	Stylus Photo 830U	●
EPSON	Stylus Photo 900	●
EPSON	Stylus Photo 915	●
EPSON	Stylus Photo EX2	●
EPSON	Stylus Photo EX3	●
EPSON	Stylus Photo R1800	●

EPSON	Stylus Photo R210	●
EPSON	Stylus Photo R230	●
EPSON	Stylus Photo R250	●
EPSON	Stylus Photo R310	●
EPSON	Stylus Photo R350	●
EPSON	Stylus Photo R2400	●
EPSON	Stylus Photo RX 430	●
EPSON	Stylus Photo RX 510	●
EPSON	Stylus Photo RX 530	●
EPSON	Stylus Photo RX 590	●
EPSON	Stylus Photo RX 630	●
EPSON	Stylus Photo RX 650	●
EPSON	ACULASER C1900	●
EPSON	EPL5700	
EPSON	EPL5800	●
EPSON	EPL5900	●
EPSON	EPL6100	●
EPSON	EPL6200	●
EPSON	EPL-N2120	
EPSON	LP2500	●
EPSON	LP8900	●
EPSON	TM T88III	
FUJITSU	DL-700	
FUJITSU	DL-900	
FUJITSU	DL-3400	
FUJITSU	DL-3800	
FUJITSU	DL-3850	
FUJITSU	DL-5800	
FUJITSU	DL-6400Pro	
FUJITSU	DL-6800	
FUJITSU	FP 410	
FUJITSU	Jet Wind 500C	
FUJITSU	PP 10	
FUTEK	F8000	
FUTEK	F84+	
FUTEK	F86+	
HP	Color Laserjet 2605	●
HP	Color Laserjet 3700	●
HP	DeskJet 400	
HP	DeskJet 450C	●
HP	DeskJet 500	
HP	DeskJet 670C	
HP	DeskJet 680C	
HP	DeskJet 720C	

HP	DeskJet 810C	●
HP	DeskJet 830C	●
HP	DeskJet 845C	●
HP	DeskJet 920C	
HP	DeskJet 930C	
HP	DeskJet 948C	●
HP	DeskJet 970CXI	●
HP	DeskJet 1120C	
HP	DeskJet 1125C	●
HP	DeskJet 1180C	●
HP	DeskJet 1220C	●
HP	DeskJet 1280	●
HP	DeskJet 3325	●
HP	DeskJet 3420	●
HP	DeskJet 3535	●
HP	DeskJet 3743	●
HP	DeskJet 3748	●
HP	DeskJet 3650	●
HP	DeskJet 3820	●
HP	DeskJet 3920	●
HP	DeskJet 3940	●
HP	DeskJet 5440	●
HP	DeskJet 5500	
HP	DeskJet 5550	●
HP	DeskJet 5652	●
HP	DeskJet 9300	●
HP	DeskJet 9600	●
HP	DeskJet 9650	●
HP	DeskJet 9800	●
HP	Business Inkjet 1000	●
HP	Designjet 100	●
HP	Designjet 600	
HP	Designjet 650C	
HP	Designjet 700	
HP	Designjet 750C+	
HP	LaserJet 1022	●
HP	LaserJet 1022N	●
HP	LaserJet 1100	
HP	LaserJet 1160	●
HP	LaserJet 1200	●
HP	LaserJet 1220	●
HP	LaserJet 1300	●
HP	LaserJet 1320	●
HP	LaserJet 2100	

HP	LaserJet 2200	
HP	LaserJet 2200D	●
HP	LaserJet 2300	●
HP	LaserJet 2410	●
HP	LaserJet 2420	●
HP	LaserJet 2500	●
HP	LaserJet 2550	●
HP	LaserJet 3015	
HP	LaserJet 3050	●
HP	LaserJet 3020	●
HP	LaserJet 3200	●
HP	LaserJet 3330	●
HP	LaserJet 3380	●
HP	LaserJet 4000	
HP	LaserJet 4050	
HP	LaserJet 4100	
HP	LasetJet 4250	●
HP	LasetJet 4300	●
HP	LaserJet 4500	
HP	LasetJet 4650	●
HP	LasetJet 5000	●
HP	LasetJet 5000LE	
HP	LasetJet 5100LE	
HP	LaserJet 6P	
HP	LaserJet 8100	
HP	LaserJet 1005 MFP	●
HP	Photosmart 2610	●
HP	Photosmart 7150	●
HP	Photosmart 7550	●
HP	Photosmart 7830	●
HP	Photosmart C3180	●
HP	Photosmart D5160	●
HP	Photosmart D7160	●
HP	PSC 1315	●
HP	PSC 1350	●
HP	PSC 1410	●
HP	PSC 1610	●
HP	PSC 2210	●
HP	PSC 2310	●
HP	OfficeJet 4255	●
HP	OfficeJet 5510	●
HP	OfficeJet 5610	●
HP	OfficeJet 6210	●
HP	OfficeJet 7210	●

HP	OfficeJet K850	●
HP	OfficeJet Pro K550	●
IBM	Infoprint 20	
IBM	Infoprint 1116	●
IBM	Infoprint 1312	●
IBM	Infoprint 1316	●
IBM	Infoprint 1332	●
IBM	Infoprint 1412	●
Konica Minolta	DI 152	
Konica Minolta	DI 250	
Konica Minolta	Pagepro 1300W	●
Konica Minolta	Pagepro 1350W	●
Konica Minolta	Pagepro 1380MF	●
Konica Minolta	Pagepro 9100	●
Konica Minolta	Magicolor 2400	●
Konica Minolta	Magicolor 2450	●
Konica Minolta	Magicolor 5450	●
Konica Minolta	Magicolor 7300	●
Kyocera	FS-1010	●
Kyocera	FS-1010KX	●
Kyocera	FS-1020	●
Kyocera	FS-1920	●
Kyocera	FS-720	●
Kyocera	FS-820	●
Kyocera	FS-920	●
Kyocera	FS-6020	●
Kyocera	KM-1635	●
LEXMARK	E210	●
LEXMARK	E322	●
LEXMARK	Optra S1250	
LEXMARK	T420	●
LEXMARK	T620	●
LEXMARK	C720	
LEXMARK	C750	●
LEXMARK	W812	●
LEXMARK	Z43	●
LEXMARK	Z45	●
LEXMARK	Z55	●
LEXMARK	Z615	●
LEXMARK	Z705	●
LEXMARK	Z42	●
LEXMARK	Z515	●
LEXMARK	X6170	●
MITAC	MP-6600C	

NEC	Pinwriter P2200	
NEC	Pinwriter P3200	
NEC	Pinwriter P5300	
NEC	PINWRITER P8000C	
OKI	Microline 391	
OKI	C3200	●
OKI	B4350	●
RICOH	NF3570	
PANASONIC	KX-P1121	
PANASONIC	KX-P1123	
PANASONIC	KX-P1124	
PANASONIC	KX-P1624	
PANASONIC	KX-P6500	
SAMSUNG	ML-1520	●
SAMSUNG	ML-1710	●
SAMSUNG	ML-1750	●
SAMSUNG	ML-2010	●
SAMSUNG	ML-2250	●
SAMSUNG	ML-2550	●
SAMSUNG	CLP 500	●
SAMSUNG	CLP 510	●
SAMSUNG	SRP 270	
SAMSUNG	SCX-4016	●
SAMSUNG	SCX-4100	●
Sharp	AR-255	
Sharp	AR-265FG	
Sharp	AR-M 160	●
Sharp	AR-M 205	●
Sharp	AR-M 207	●
Sharp	AR-M 235	●
Sharp	AR-M 275	●
Sharp	AR-M 350	●
Sharp	AR-M 351U	●
Sharp	AR-M 400	●
Sharp	AR-M 450	●
STAR	NX-2420	
TOSHIBA	E-161	
TOSHIBA	Estudio-25	
XEROX	Phaser 3310	●
XEROX	Able 3321	
XEROX	Docuprint 240A	●